


BLOCK DIAGRAM




CAR FREQUENCY

MODE	FREQUENCY(MHz)
USB	10.6935
CW(R)	10.6935
CW(T)	10.6943
LSB	10.6965


HET FREQUENCY(VCO)

MODE	FREQUENCY(MHz)
FM	133.305 ~ 135.304
USB	133.3065 ~ 135.3064
LSB	133.3035 ~ 135.3034

BLOCK DIAGRAM



TR-9130 SCHEMATIC DIA



SCHEMATIC DIAGRAM

